

SPARE PARTS LIST

MODEL NO. 9207SPB

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
002	911261-6	PAN HEAD SCREW M5X40	4	
004	212005-0	NEEDLE BEARING 810	1	
005	961052-5	RETAINING RING S-12	1	
006	221312-0	SPIRAL BEVEL GEAR 43	1	
007	285805-1	BEARING RETAINER 22-34	1	
008	211106-1	BALL BEARING 6201LLB	1	
009	312795-6	BEARING BOX	1	
010	911121-2	PAN HEAD SCREW M4X14	4	
011	213301-9	DUST SEAL 20	1	
012	254002-0	WOODRUFF KEY 3	1	
013	325527-2	SPINDLE	1	
014	224523-6	SANDING LOCK NUT 16-48	1	
015	133324-0	GEAR HOUSING ASS'Y INC. 4	1	
016	285816-6	BEARING RETAINER 19-33	1	
017	961055-9	RETAINING RING S-15	1	
018	211201-7	BALL BEARING 6002LLB	1	
019	312722-3	GEAR HOUSING COVER	1	
020	241080-9	FAN 68	1	
021	512549-3	ARMATURE ASS'Y 220V INC. 20,23,25	1	220V
022	911295-9	PAN HEAD SCREW M5X70	2	
023	681613-2	INSULATION WASHER	1	
024	263014-2	RUBBER PIN 4	1	
025	211033-2	BALL BEARING 608LB	1	
026	411263-7	BAFFLE PLATE	1	
027	522335-4	FIELD ASS'Y 220V	1	220V
028	156125-9	MOTOR HOUSING INC. 24	1	
029	181030-1	CARBON BRUSH CB-100	1	
030	643600-9	BRUSH HOLDER CAP 6-10	2	
031	811870-0	NAME PLATE 9207SPB	1	
032	953106-2	RIVET 0-5	2	
033	651600-5	SWITCH SS106A	1	
034	631011-0	DIODE S3V60ZM-H	1	220V/240V
035	651018-0	SWITCH HPAHR2-3S	1	
036	911103-4	PAN HEAD SCREW M4X6	2	
037	911168-6	PAN HEAD SCREW M4X40	2	
038	411262-9	HANDLE COVER	1	
039	911148-2	PAN HEAD SCREW M4X25	2	
041	911133-5	PAN HEAD SCREW M4X18	2	
042	687001-1	STRAIN RELIEF	1	
043	682504-0	CORD GUARD 10-85	1	
044	691015-4	POWER SUPPLY CORD 0.75-2-2.5	1	
400	743012-7	RUBBER PAD 170	1	
401	794094-2	ABRASIVE DISC 180 #50	1	
404	782412-6	LOCK NUT WRENCH 28	1	
405	781008-0	WRENCH 17	1	

SERVICE DRAWING

MODEL NO. 9207SPB

